



HOW TO CHANGE YOUR PHONE SETTINGS WHILE ROAMING


Search for and choose a network manually



From the home screen
click the menu button




Click the settings icon




Click mobile networks




Search for and choose a network manually



Click on service providers



Click on search mode
And change to manual



Click search networks
a list of available networks is
displayed.
Click your preferred network to
activate it




Changing Access Point Name (APN)



From the home screen
click the menu button




Click the settings icon




Click mobile networks

Select between 2G and 3G networks



Click Access Point Names



Click on menu and choose new
Type in the APN settings
Click menu and save


Select between 2G and 3G networks



From the home screen
click the menu button




Click the settings icon




Click mobile networks

Select between 2G and 3G networks



Click network mode



Click on your preferred mode
GSM is the same as 2G while
WCDMA is the same as 3G



A list of APN's is displayed
Click on your preferred APN
to activate it